

COLOR COAT TIPS FOR SEALING CONCRETE

- Before using Color Coat, make sure that you stir thoroughly before you begin, and periodically throughout the application (ie. before you refill your tray). This ensures consistent color across the floor.
- Recommended to use a 10 mil lint free roller.
- Use a paint tray to hold the product, and roll from the tray. DO NOT pour in puddles on the floor and spread from there.
- Paint in sections, use the saw cut lines as a guide.
- Lightly roll out colored acrylic in one direction, making sure to keep a wet edge. If roller edges occur, you are applying too much weight to the roller. If this occurs, go back to the beginning of the section, and lightly roll out again.
- Do not leave puddles of product on the surface. Roll out any puddled areas.
- Spraying is not recommended, but if you need to get the product onto the surface, you can spray it on making sure to roll it out as you go.
- If fisheyes occur (ie. separation of the product when it contacts the surface within 5 minutes of application), this is a good indication that the floor surface is contaminated with a foreign material. In some cases, not in all, fisheyes can be reduced by working the Color Coat into the surface with your roller. Use a circular and sideways motion and extra weight on the roller to scrub the product into the surface.

If fisheyes are a continual problem on the floor, you need to stop the application, and clean and dry the floor thoroughly before continuing.